



## EXCHANGING SEAT PILLARS ON A BROMPTON.

Remember that whenever you are fitting a fresh Seat Pillar, you will probably have to adjust the seat clamp quick release on the main frame (Seat Pillars can vary slightly in diameter).

With the Seat Pillar raised, the closing force (when pushing on the end of the black nylon lever QR) should be in the range 80-120N. A very small adjustment of the nut AN makes a big difference to the closing force. It is dangerous to use the bike if this clamp is too loose: and, if it is too tight, the frame can become permanently damaged.

